

Ham 94C– ASV Advance – IAX password

Dr. Marc & Rosemary © 230215

1. One of the challenges is when password needs to be accessed.
 - a. This occurs if an incompatible password is entered when compared to the AllStarLink.org password.
 - b. It is a simple change in one file.
2. Nano *iax.conf*
 - a. Look for the registration line.
 - b. `xxxxx:yyyyyy` is node number:password.
 - c. Comment out the original line. Add one line with the correct information.

nano iax.conf

```
; Include hamvoip registration
```

```
#includeifexists iax-hamvoip.conf
```

```
;register => xxxxx:yyyyyy@register.allstarlink.org
```

```
register => 58000:PassWord@register.allstarlink.org
```

3. Exit the file. Exit CLI.
4. Reboot to make the password change active.

